
PLC LIGHTING

21141 21143 21145

INSTALLATION INSTRUCTIONS:



- 1, Ensure mains supply is switch off.
- 2, Fit crossing bar (A) onto mounting surface with self-tapping screws.
- 3, Make the wiring connections: Using wire connectors (B) connect the house white wire(s) to the fixture white(or ribbed) lead(s); connect the house black(or red) wire(s) to the fixture black(or smooth) lead(s). Make sure there are no exposed wires or stands, and the connections are secured.
- 4, Fit mounting box(C) onto crossing bar with screws (D).
- 5, Fit bulbs (E) firmly into lampholders(F).
- 6, Fit glass shade (G) onto fitting and secured with washer & nut (H).

WARNING:

- Electricity supply required 110-120v 60 htz alternating current.
- Use only the correct light bulbs as stipulated on the luminaries .
- Disconnect the power and allow fitting cool down before cleaning or changing bulb(s).
- If any malfunction occurs, switch of mains and contact a qualified electrician.
- Do not modify this unit in any manner.